



Beyond The Surface

Information from Pro Wood

Chemlife 24 Conversion Varnish

Always catalyze first, then reduce (thin). However, once catalyzed, Chemlife 24 is designed to be sprayed without further reduction.

Do not use steel wool to sand between coats.

Always spray acid catalyzed coatings in an environment of 60°F or above.