



*Beyond The Surface*

## **Information from Pro Wood**

### *Plasticolor Pigmented Conversion Varnish*

Always catalyze first, then reduce (thin).

In our experience, this product must be reduced for maximum performance and will vary per spray equipment.

Always use 803-1325 Compliant Reducer for reduction.

Do not use steel wool to sand between coats.

Always spray acid catalyzed coatings in an environment of 60°F or above.