



Beyond The Surface

Info from Pro Wood Sheet

When using polyester sealers, always apply Isolante Barrier Coat Sealer (401-033) first.